

Environmental Health & Safety SOP: Dartmouth College Title:

Title: Removal of ACM Flooring

{29 CFR 1926.1101(8)(i)},{29 CFR 1926.1101(9)(iv)},{Env-C 406.02}

Purpose: To address removal of asbestos containing floor material.

Scope: This applies to all Dartmouth College Employees.

Responsibilities:

- Supervisors will inform EHS when asbestos flooring is being removed.
- Supervisors will not ask employees who have not been trained to remove asbestos containing flooring.
- Workers must have successfully completed a 16 hour training course. And 4 hour refresher trainings annually.
- EHS will conduct air and bulk sampling and Negative Exposure Assessments as necessary.

Procedure:

- Air monitoring is required, respirators and protective clothing must be worn unless a negative exposure assessment has been performed.
- Resilient flooring material including mastic and backing shall be assumed to be asbestos containing unless an industrial hygienist determines that it is asbestos-free using recognized analytical techniques.
- Flooring or its backing shall not be sanded, drilled, sawn or otherwise abraded.
- Vacuums equipped with HEPA filters, disposable dust bag, and metal floor tool (no brush) shall be used to clean floors.
- Resilient sheeting shall be removed by cutting. Wetting of the snip point and wetting during delamination is required. Rip-up of resilient sheet floor material is prohibited.
- All scraping of residual adhesive and /or backing shall be performed using wet methods.
- · Dry sweeping is prohibited.
- Mechanical chipping is prohibited.
- Tiles shall be removed intact unless, the employer demonstrates that intact removal is not possible.
- Adequately wet the flooring in the work area prior to ACM removal.
- When tiles are heated and can be removed intact, wetting may be omitted.
- All liquids used in removal shall be disposed of as asbestos-containing waste.
- Flooring must be placed in asbestos disposal bags, no more than 50 lbs./bag. Labels identifying where the material came from, account number, etc. must be affixed to the bag. Labels are available at the tool crib or through EHS. The bag is then placed in the hazardous waste storage area for disposal by an asbestos contractor and EHS must be notified.
- All waste must be disposed of in landfills approved for acceptance of asbestos waste and packaged to the specifications established by the individual landfill.

FO&M Ap	proved:			Approval date:	
EHS Approved:				Revision date:	
Page #	1	Original Date:	April 4,2017	Revision #	Orig.